

# AKAI SERVICE MANUAL





**DIGITAL INTEGRATED AMPLIFIER** 

MODEL AM-M600 MODEL AM-M800

#### $\mathbf{x}$


#### PRECAUTIONS DURING SERVICING

- Parts identified by the (\*) symbol are critical for safety. Replace only with parts number specified.
- 2. In addition to safety, other parts and assemblies are specified for conformance with such regulations as those applying to spurious radiation.

These must also be replaced only with specified replacements.

Examples: RF converters, tuner units, antenna selector switches, RF cables, noise blocking capacitors, noise blocking filters, etc.

- 3. Use specified internal wiring. Note especially:
  - 1) Wires covered with PVC tubing
  - 2) Double insulated wires
  - 3) High voltage leads
- Use specified insulating materials for hazardous live parts. Note especially:
  - 1) Insulation Tape
  - 2) PVC tubing
  - 3) Spacers (Insulating Barriers)
  - 4) Insulation sheets for transistors
  - 5) Plastic screws for fixing microswitch (especially in turntable)
- When replacing AC primary side components (transformers, power cords, noise blocking capacitors, etc.), wrap ends of wires securely about the terminals before soldering.



- Observe that wires do not contact heat producing parts (heatsinks, oxide metal film resistors, fusible resistors, etc.).
- Check that replaced wires do not contact sharp edged or pointed parts.
- 8. Also check areas surrounding repaired locations.
- Use care that foreign objects (screws, solder droplets, etc.) do not remain inside the set.

#### SAFETY CHECK AFTER SERVICING

After servicing, make measurements of leakage-current or resistance in order to determine that exposed parts are acceptably insulated from the supply circuit.

The leakage-current measurement should be done between accessible metal parts (such as chassis, ground terminal, microphone jacks, signal-input/output connectors, etc.) and the earth ground through a resister of 1500 ohms paralleled with a 0.15  $\mu F$  capacitor, under the unit's normal working conditions. The leakage-current should be less than 0.5 mA rms AC.

The resistance measurement should be done between accessible exposed metal parts and power cord plug prongs with the power switch (if included) "ON". The resistance should be more than 2.2 Mohms.

#### **★INFORMATION**


#### SYMBOLS FOR PRIMARY DESTINATION

Alphabet indicates the destination of the units as listed below.

Symbols	Principal Destinations
В	UK
E)	Europe (except UK)
S	Australia
V	W. Germany only
U	Universal Area
Y*	Custom version

#### **VOLTAGE CONVERSION (U Model only)**

Before connecting the power cord, set the VOLTAGE SE-LECTOR located on the rear panel so that the correct voltage for your area is indicated.



## PRECAUTION BEFORE/AFTER REPAIRING THE UNIT

[ ABOUT THE POWER SUPPLY ]

Power supply of the AM-M600/M800 is controlled by the tuner. Therefore when repair of the AM-M600/M800 is necessary, repair should be made together with the tuner.

To repair the AM-M600/M800 without tuner, use the following procedure.

- 1) While pushing the G.E REC button, press the POWER button to turn the power of the AM-M600/M800 on.
- 2) To turn off the power of the AM-M600/M800, the AC power cord must be disconnected.

#### **MODEL AM-M600**

Power output	
FTC	33 W × 2 (6 ohms, 40 Hz to
	20 kHz, THD 0.2 %)
DIN	
EIAJ	
Music	
PMPO	
	10 Hz to 50 kHz (THD 0.1
	%)
Total harmonic distortion .	
Phono max. input level	50 mV (1kHz)
Frequency response	10 Hz to 100 kHz (+1.5 dB, -6.0 dB)
Tone control	, , ,
Treble	+ 8.0 dB (10 kHz)
Bass	
S/N ratio (IHF-A)	_ 0.0 02 (700)
PHONO (MM)	72 dB
Others	
Residual noise	
Channel separation	
Damping factor	
Required speaker imped	
ance	-
A or B	6 4a 16 abma
Input sensitivity / imped	
	4 m)/ / 47 kohma
PHONO (MM)	
VCR, etc.	
Output level / impedance	.300 mV / 1 konms
[ DAC section]	
Sampling frequency	
Digital filter	
D/A convertor	18 bit / 2 DAC
Digital input level	
OPTICAL	
Frequency response	
Dynamic range	93 dB
	0.04 % (1 kHz, 20 kHz LPF)
Power requirements	AC 220 V, 50 Hz for Europe
	except UK
	AC 240 V, 50 Hz for UK
	and Australia
	AC 110 / 120 / 220 / 240
	V, 50 / 60 Hz convertible
	for other countries.
Dimensions	360 (W) × 117 (H) × 310 (D)
	mm
Weight	
	9
Standard accessoriles	
Remote control unit (RC-S	Se00) 1
Batteries	
Operator's manual	
Operator's manual	


#### **MODEL AM-M800**

Power output
FTC 54 W × 2 (6 ohms, 40 Hz to
20 kHz, THD 0.2 %)
DIN
EIAJ 73 W × 2 (6 ohms)
Music
PMPO 670 W
Power bandwidth
%)
Total harmonic distortion 0.06 % (1 kHz)
Phono max. input level 50 mV (1kHz)
Frequency response 10 Hz to 100 kHz (+1.5 dB,
-6.0 dB)
Tone control
Treble ± 8.0 dB (10 kHz)
Bass ± 8.0 dB (100 Hz)
S/N ratio (IHF-A)
PHONO (MM) 73 dB
Others 88 dB
Residual noise 0.5 mV
Channel separation 60 dB (1 kHz)
Damping factor 19.3
Required speaker imped-
ance
A or B 6 to 16 ohms
A and B 12 to 16 ohms
Input sensitivity / imped-
ance
PHONO (MM) 4 mV / 47 kohms
VCR, etc 300 mV / 47 kohms
Output level / impedance . 300 mV / 1 kohms
[ DAC section ]
Sampling frequency 32 / 44.1 / 48 kHz
Digital filter 8 fs / 18 bit
D/A convertor 18 bit / 2 DAC
Digital input level / im-
pedance
OPTICAL14 to -23 dBm
COAXIAL 0.5 Vp-p / 75 ohms
Frequency response 20 Hz to 20 kHz ± 0.5 dB
Dynamic range 95 dB
Total harmonic distortion 0.008 % (1 kHz, 20 kHz
LPF)
Power requirements AC 220 V, 50 Hz for Europe
except UK
AC 240 V, 50 Hz for UK
and Australia
AC 110 / 120 / 220 / 240
V, 50 / 60 Hz convertible
for other countries.
Dimensions 360 (W) × 117 (H) × 310 (D)
mm
Weight 6.4 kg
Standard accessoriles
Remote control unit (RC-S600) 1
Batteries2
Operator's manual 1

 $oldsymbol{*}$  For improvement purposes, specifications and design are subject to change without notice.

#### I. DISASSEMBLY

In case of trouble, etc., necessitating dismantling, please dismantle in the order shown in the illustrations. Reassemble in reverse order.



#### II. PRINCIPAL PARTS LOCATION




Fig. 2-1 Top view

#### **ATTENTION**

- 1. When placing an order for parts, be sure to list Part No., Model No. and the description of eachpart. Otherwise, the non-delivery of the part or the delivery of a wrong part may result.
- 2. Please make sure that Part No. is correct when ordering.
  If not, a part different from the one you ordered may be delivered.
- 3. Since the parts shown in Parts List of Preliminary Service Manual may have been the subject of changes, please use this Parts List for all future reference.

#### **HOW TO USE THIS PARTS LIST**

- 1. This Parts List lists those parts which are considered necessary for repairs. Other common parts, such as resistors and capacitors, are listed in the "Common List for Service Parts" from which these parts should be selected and stocked.
- 2. The Recommended Spare Parts List shows those parts in the Parts List which are considered particularly important for service.
- 3. Parts not shown in the Parts List and "Common List for Service Parts" will not in principle be supplied.
- 4. How to read the Parts List.
  - a) Mechanism Block

#### 2. HEAD BASE BLOCK

Ref.No. Part No. Description BH-T2023A320A HEAD BASE BLOCK 2 HP-H2206A010A HEAD R/P PR4-8FU C 3 ZS-477876 PAN20×03STL CMT 75-536488 BID20×08STL CMT 5 ZG-402895 SP CS ANGLE ADJUST SP (Service Parts) Classification This number corresponds with the individ ual parts index number in that figure.

b) PC Board

#### 6. MAIN PC BOARD

Ref.No.	Part No.	Description
IC1	EI-324536	IC HD14049BP
IC2	El-336801	IC MB8841-564M
C1A	EC-338399	C MMY V 223M 250AC [U,E,B,S]
C1B	EC-350949	C MMY V 223M 250DC [J]
C1C	EC-338397	C MMY V 223M 125AC [C,A]
X1	EI-318384	OSC X'TAL NC-18C
	[A]: AAL (U. [B]: BEAB (E [C]: CSA (Ca [E]: CEE (Eu [J]: JPN (Ja	urope) [V]: VDE (W. Germany) nan) [Y]: Custom Version
	SP (Ser	rvice Parts) Classification
These reference symbols correspond with component symbols in the Schematic Diagrams.		

The available PC Board Blocks are listed separately.

5. When Part No. is known, Parts Index at end of Parts List can be used to locate where that part is shown in Parts List by its Reference No.listed at right of Part No.

#### WARNING

 $\triangle$  (\*) INDICATES SAFETY CRITICAL COMPONENTS. FOR CONTINUED SAFETY, REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURE'S RECOMMENDED PARTS.

#### **AVERTISSEMENT**

△ (\*) IL INDIQUE LES COMPOSANTS CRITIQUES DE SÉCURITÉ. POUR MAINTENIR LE DEGRÉ DE SÉCURITÉDE L'APPAREIL, NE REMPLACER QUE DES PIÉCES RECOMMANDEES PAR LÉ FABRICANT.

#### 1.RECOMMENDED SPARE PARTS

We suggest you to stock the following Recommended Spare Part items listed below since they can cover most of the routine service.

- 4 N -	David No.	Description
Ref.No.	Part No.	Description
1	AX-394557M	REMOCON RC-S600
2	*BT-394528J	TRANS POW A2067(B) [AM-M800]
3	*BT-394527J	TRANS POW A2067(E)
	J.DT 00 4500 4	[AM-M800]
4	*BT-394526J	TRANS POW A2067(U) [AM-M800]
5	*BT-394524J	TRANS POW A2068(B)
_		[AM-M600]
6	*BT-394523J	TRANS POW A2068(E) [AM-M600]
7	*BT-394522J	TRANS POW A2068(U)
		[AM-M600]
8	ED-394509J	D LED GL3HY43 ORANGE
9	ED-382365J	D LED SLR-34VC3F RED
10	ED-394416J	D LED SLV-31VT3F RED
11	ED-307572	D SILICON H 1SS131
12	ED-394453J	D SILICON H 1SS92T-77 T26
13	ED-394708J	D SILICON RBA402 200/4.0A
		[AM-M600]
14	ED-384278J	D SILICON RBV602 200/6.0A
4.5	.UED 0000404	[AM-M800]
15	*ED-389840J	D SILICON 1SR139-100HS F10
16	ED-346627	D ZENER H HZ33 2
17	ED-331617	D ZENER H HZ6 A3
18	ED-346530	D ZENER H HZ6C3L
19 -	ED-346604	D ZENER H HZ7 B2
20	ED-346535	D ZENER H HZ7C2L
21	*EF-601301	FUSE SEMKO T 250V 2.00A
		[U]
22	*EF-691007	FUSE SEMKO T 250V 3.15A
	. ==	[AM-M600]
23	*EF-690996	FUSE SEMKO T 250V 4.00A
24	*EF-593706	[AM-M800] FUSE SEMKO T 250V 500MA
25	*EF-601942	FUSE SEMKO T 250V 630MA
26	EI-390595J	IC AD1860N
27	EI-367572	IC BA15218
28	EI-382660J	IC BA15218-DX
29	EI-394932J	IC LC6520C-4406 FXAMP2
30	El-394508J	IC MC14051B
31	El-361133	IC MC14053B
32	El-393324J	IC M5218AL
33	EI-392838J	IC PD0050
34	EI-390594J	IC PD0052
35	El-381024J	IC SM5807EP
36	<b>≭E</b> I-358554	IC STK4152II
		[AM-M600]
37	*El-366695	IC STK4172II
38	E1 2222E0	[AM-M800]
50	El-332259	IC TC4052BP [AM-M800]
39	El-360040J1	IC TC74HCU04AP
40	El-394518J	IC UPD6376CX
41		OSC CE KBR-4.19M 4.19MHZ
42	EI-719635 EQ-394450J	RELAY POW DG12D1-O(M) 12V
	EQ-0344000	[U]
43	*ER-200746	R FUSE H ERD2FC 1/4W 1000G
44	*ER-332225	R FUSE H S10 ERD2FC 1/4W 56R0G
45	*ER-331188	R FUSE H S10 ERD2FC 1/4W 8R2J
46	ES-394512J	SW PUSH SPEA12 02-02N
40	L3-3343120	[AM-M800]
47	*ES-349070	SW SELECTOR YKS11-0002 02-4
		[ບ]
48	ES-394493J	SW TACT SOA-123HS
40	E0 00 17:01	[FUNC.DOWN]
49 50	ES-394513J	SW TACT SOA-143HS
50	ET-356336	TR DTA114ES
51	ET-363953	TR DTA114TS
52	ET-353897	TR DTC114ES
53	ET-354371	TR DTC124ES
54	ET-370311	TR DTC143XS
		[AM-M800]

Ref.No.	Part No.	Description
55	ET-354414	TR DTC144ES
56	ET-368249	TR DTD114TS
57	ET-749377	TR 2SA1048 GR
58	ET-353899	TR 2SA1317 S,T,U
59	ET-394600J	TR 2SA684 Q,R T05
60	ET-366365	TR 2SB1185 E,F
		[U]
61	ET-373210	TR 2SB1187 E,F
62	ET-749375	TR 2SC2458 GR
63	ET-338410	TR 2SC2878 A,B
64	ET-397160J	TR 2SC3330 R,S,T,U,V
65	ET-378524J	TR 2SC3383 S,T,U
66	ET-380685J	TR 2SD1761 E,F,G
67	ET-373025	TR 2SD1944 J1,J2,K
68	EV-394517J	VR ROTARY RK11K113 SPCL W104
69	EV-394515J	VR ROTARY RK14K1230 B103X2
70	EV-394458J	VR SPL RK16Y12MA A104X2

#### 2. P.C BOARD

Ref.No.	Part No.	Description
1	BA-A2068A020A	PC(#) MAIN AMP BLK AM-M600(U) [U] [AM-M600]
2	BA-A2068A020C	PC(#) MAIN AMP BLK AM-M600(V) [E,V,B] [AM-M600]
3	BA-A2068A020D	
4	BA-A2068A020F	PC(#) MAIN AMP BLK AM-M800(V) [E,V,B] [AM-M800]
5	BA-A2068A040B	PC DAC-A BLK AM-M600(V) [AM-M600]
6	BA-A2067A040B	PC DAC-B BLK AM-M800(V) [AM-M800]
7	BA-A2068A030B	PC(#) CONTROL BLK AM-M600(V) [AM-M600]
8	BA-A2068A030D	PC(#) CONTROL BLK AM-M800(V) [AM-M800]

PC (#) MAIN AMP BLK CONSISTS OF FOLLOWING P.C BOARD.

- MAIN AMP P.C BOARD
- CONNECTOR P.C BOARD
- POWER P.C BOARD
- FUSE-1 P.C BOARD
  FUSE-2 P.C BOARD

PC (#) CONTROL BLK CONSISTS OF FOLLOWING P.C BOARD.

- CONTROL P.C BOARD
- VR P.C BOARD
- PHONE P.C BOARD
- LED P.C BOARD

#### 3. MAIN AMP P.C BOARD

Description

Ref.No. Part No.

Het.No.	Part No.	Description
D1	ED-394453J	D SILICON H 1SS92T-77 T26
		D ZENER H HZ7 B2
D2	ED-346604	
D101	*ED-389840J	D SILICON 1SR139-100HS F10
D102	*ED-389840J	D SILICON 1SR139-100HS F10
D103	*ED-389840J	D SILICON 1SR139-100HS F10
D104	*ED-389840J	D SILICON 1SR139-100HS F10
D105	ED-346535	D ZENER H HZ7C2L
D106	ED-346535	D ZENER H HZ7C2L
D107	ED-307572	D SILICON H 1SS131
		D SILICON H 1SS131
D108	ED-307572	
D109	*ED-389840J	D SILICON 1SR139-100HS F10
D110	*ED-389840J	D SILICON 1SR139-100HS F10
D111	*ED-389840J	D SILICON 1SR139-100HS F10
D112	*ED-389840J	D SILICON 1SR139-100HS F10
D113	ED-346530	D ZENER H HZ6C3L
D115	*ED-389840J	D SILICON 1SR139-100HS F10
D116	*ED-389840J	D SILICON 1SR139-100HS F10
D117	*ED-389840J	D SILICON 1SR139-100HS F10
D118	*ED-389840J	D SILICON 1SR139-100HS F10
D119	*ED-389840J	D SILICON 1SR139-100HS F10
D120	*ED-389840J	D SILICON 1SR139-100HS F10
D121	ED-346627	D ZENER H HZ33 2
D123A	ED-394708J	D SILICON RBA402 200/4.0A
		[AM-M600]
D123B	ED-384278J	D SILICON RBV602 200/6.0A
0.200	ED 00 1E7 00	[AM-M800]
E101A	<b>₩</b> EE 600105	FUSE SEMKO T 250V 2.50A
F101A	*EF-623125	
		[AM-M600]
F101B	*EF-691007	FUSE SEMKO T 250V 3.15A
		[AM-M800]
FR1	*ER-200746	R FUSE H ERD2FC 1/4W 1000G
FR2	*ER-200746	R FUSE H ERD2FC 1/4W 1000G
ER101	*ER-331188	R FUSE H S10 ERD2FC 1/4W 8R2J
FR102	*ER-332225	R FUSE H S10 ERD2FC 1/4W 56R0G
IC1	EI-382660J	IC BA15218-DX
		IC MC14051B
IC2	El-394508J	
IC3	EI-394508J	IC MC14051B
IC4	El-361133	IC MC14053B
IC5	El-361133	IC MC14053B
1C6	El-367572	IC BA15218
IC7	El-367572	IC BA15218
		[AM-M800]
IC8	EI-332259	IC TC4052BP
100	LI OOLLOO	[AM-M800]
101014	AEI 050554	IC STK4152II
IC101A	*EI-358554	
	. =	[AM-M600]
IC101B	*EI-366695	IC STK4172II
		[AM-M800]
J1A	EJ-394438J	PIN J YKC21-3050 SEALED 6P
		[E,U]
J1B	EJ-394437J	PIN J YKC21-3036 6P
		[V]
J2A	EJ-394436J	PIN J YKC21-3034 4P
JZA	L0-0344000	
IOD	E   0044071	[AM-M600]
J2B	EJ-394437J	PIN J YKC21-3036 6P
		[AM-M800]
J3	EJ-390597J	SOCKET 52303-1511 15P
J4	EJ-394442J	SOCKET 52303-1211 12P
R110	ER-333023	R OMF H S20 FS 2W 100J
R111	ER-333023	R OMF H S20 FS 2W 100J
TM1A	EJ-349417	TERMINAL LEVER YKD21-0026 4P
110.171	20 040417	[AM-M600]
TAME	E 1 240404	TERMINAL LEVER YKD21-0027 8P
TM1B	EJ-349401	
		[AM-M800]
TR1	ET-368249	TR DTD114TS
TR4	ET-356336	TR DTA114ES
TR5	ET-354371	TR DTC124ES
TR6	ET-354371	TR DTC124ES
TR101	ET-354371	TR DTC124ES
TR102	ET-380685J	TR 2SD1761 E,F,G
TR102		TR 2SB1187 E,F
	ET-373210	
TR104	ET-373025	TR 2SD1944 J1,J2,K
TR105	ET-373210	TR 2SB1187 E,F
TR106	ET-749377	TR 2SA1048 GR

#### 4. DAC-A P.C BOARD (AM-M600)

Ref.No.	Part No.	Description
D1	ED-307572	D SILICON H 1SS131
D2	ED-307572	D SILICON H 1SS131
D3	ED-331617	D ZENER H HZ6 A3
D4	ED-307572	D SILICON H 1SS131
D5	ED-307572	D SILICON H 1SS131
FL1	EH-386589J	FILTER EMI FBA04HA600AB-00 T26
FL2	EH-386589J	FILTER EMI FBA04HA600AB-00 T26
FL3	EH-386589J	FILTER EMI FBA04HA600AB-00 T26
FL4	EH-395074J	FILTER EMI FBA04HA600VB-00 T05
IC1	El-390594J	IC PD0052
IC2	EI-381024J	IC SM5807EP
1C3	El-394518J	IC UPD6376CX
IC4	EI-393324J	IC M5218AL
J1	EJ-394459J	SOCKET OPTICAL GP1F32R
TR1	ET-378524J	TR 2SC3383 S,T,U
TR2	ET-354414	TR DTC144ES
TR3	ET-356336	TR DTA114ES
TR4	ET-354414	TR DTC144ES
TR5	ET-356336	TR DTA114ES
TR6	ET-354414	TR DTC144ES
TR7	ET-394600J	TR 2SA684 Q,R T05
TR8	ET-749375	TR 2SC2458 GR
TR9	ET-749375	TR 2SC2458 GR
TR10	ET-749375	TR 2SC2458 GR
TR11	ET-749375	TR 2SC2458 GR
TR12	ET-354414	TR DTC144ES
TR13	ET-354414	TR DTC144ES
TR14	ET-749375	TR 2SC2458 GR

#### 5. DAC-B P.C BOARD (AM-M800)

Ref.No.	Part No.	Description
D1	ED-307572	D SILICON H 1SS131
D2	ED-307572	D SILICON H 1SS131
D3	ED-307572	D SILICON H 1SS131
FL1	EH-395074J	FILTER EMI FBA04HA600VB-00 T05
FL2	EH-386589J	FILTER EMI FBA04HA600AB-00 T26
FL3	EH-386589J	FILTER EMI FBA04HA600AB-00 T26
FL4	EH-395074J	FILTER EMI FBA04HA600VB-00 T05
IC1	EI-360040J1	IC TC74HCU04AP
IC2	El-390594J	IC PD0052
IC3	El-392838J	IC PD0050
IC4	EI-390595J	IC AD1860N
IC5	EI-390595J	IC AD1860N
IC6	El-393324J	IC M5218AL
J1	EJ-394459J	SOCKET OPTICAL GP1F32R
J4	EJ-394461J	PIN J *A2076-1 3P
J5	EJ-390593J	PIN J *A2076-2 3P
T1	BT-368261	TRANS PULSE TC-1027-04
TR1	ET-354414	TR DTC144ES
TR2	ET-354414	TR DTC144ES
TR3	ET-356336	TR DTA114ES
TR4	ET-354414	TR DTC144ES
TR5	ET-356336	TR DTA114ES
TR6	ET-749375	TR 2SC2458 GR
TR7	ET-749375	TR 2SC2458 GR
TR8	ET-749375	TR 2SC2458 GR
TR9	ET-749375	TR 2SC2458 GR

#### 6. CONTROL P.C BOARD

Ref.No.	Part No.	Description
D501	ED-307572	D SILICON H 1SS131
D502	ED-307572	D SILICON H 1SS131
D504	ED-307572	D SILICON H 1SS131
D505	ED-307572	D SILICON H 1SS131
D506	ED-307572	D SILICON H 1SS131
D507	ED-307572	D SILICON H 1SS131
D508	ED-394509J	D LED GL3HY43 ORANGE

Ref.No.	Part No.	Description
D509	ED-394509J	D LED GL3HY43 ORANGE
D510	ED-394509J	D LED GL3HY43 ORANGE
D511	ED-394416J	D LED SLV-31VT3F RED
D512	ED-394416J	D LED SLV-31VT3F RED
D513	ED-394416J	D LED SLV-31VT3F RED
D514	ED-394416J	D LED SLV-31VT3F RED
D515	ED-382365J	D LED SLR-34VC3F RED
D516	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D517	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D518	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
IC501	El-367572	IC BA15218
IC502	El-367572	IC BA15218
IC503	EI-394932J	IC LC6520C-4406 FXAMP2
SW501	ES-394512J	SW PUSH SPEA12 02-02N
		[AM-M800]
SW502	ES-394512J	SW PUSH SPEA12 02-02N
		[AM-M800]
TR501	ET-353897	TR DTC114ES
TR502	ET-354371	TR DTC124ES
TR503	ET-356336	TR DTA114ES
TR504	ET-353897	TR DTC114ES
TR505	ET-353897	TR DTC114ES
TR506	ET-353897	TR DTC114ES
TR507	ET-363953	TR DTA114TS
TR508	ET-363953	TR DTA114TS
TR509	ET-363953	TR DTA114TS
TR510	ET-363953	TR DTA114TS
TR511	ET-354414	TR DTC144ES
TR512	ET-749377	TR 2SA1048 GR
TR513	ET-749375	TR 2SC2458 GR
TR514	ET-370311	TR DTC143XS
		[AM-M800]
TR515	ET-338410	TR 2SC2878 A,B
TS501	ES-394513J	SW TACT SOA-143HS
TS502	ES-394513J	SW TACT SOA-143HS
VR501	EV-394515J	VR ROTARY RK14K1230 B103X2
VR502	EV-394515J	VR ROTARY RK14K1230 B103X2
VR503	EV-394517J	VR ROTARY RK11K113 SPCL W104
X501	EI-719635	OSC CE KBR-4.19M 4.19MHZ

#### 7. VR P.C BOARD

Ref.No.	Part No.	Description
D601	ED-394453J	D SILICON H 1SS92T-77 T26
TR601	ET-353899	TR 2SA1317 S,T,U
TR602	ET-353899	TR 2SA1317 S,T,U
TR603	ET-397160J	TR 2SC3330 R,S,T,U,V
TR604	ET-397160J	TR 2SC3330 R,S,T,U,V
VR601	EV-394458J	VR SPL RK16Y12MA A104X2

#### 8. CONNECTOR P.C BOARD

Ref.No.	Part No.	Description
J201	EJ-394445J	SOCKET 52303-1411 14P

#### 9. PHONE P.C BOARD

Ref.No.	Part No.	Description
J801A	EJ-394455J	PHONE J 3P YKB21-5006 6.3 [AM-M600]
J801B	EJ-355011	PHONE J 3P YKB21-5010 6.3 [AM-M800]
R801	ER-325843	R OMF H S15 FS 1W 391J

#### 10. LED P.C BOARD

Ref.No.	Part No.	Description
D701	ED-394509J	D LED GL3HY43 ORANGE
D702	ED-394509J	D LED GL3HY43 ORANGE
D703	ED-394509J	D LED GL3HY43 ORANGE
D704	ED-394509J	D LED GL3HY43 ORANGE
D705	ED-394509J	D LED GL3HY43 ORANGE
D706	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D707	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D708	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D709	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D710	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
D711	ED-394509J	D LED GL3HY43 ORANGE
		[AM-M800]
T\$701	ES-394493J	SW TACT SOA-123HS
		[FUNC.DOWN]
TS702	ES-394493J	SW TACT SOA-123HS
		[FUNC.UP]
TS703	ES-394493J	SW TACT SOA-123HS
		[AM-M800,TURBO]

#### 11. POWER P.C BOARD

Ref.No.	Part No.	Description
D301	ED-346558	D ZENER H HZ12B1L [U]
D302	ED-307572	D SILICON H 1SS131 [U]
D303	ED-307572	D SILICON H 1SS131 [U]
D304	ED-307572	D SILICON H 1SS131
F301	*EF-601301	FUSE SEMKO T 250V 2.00A
F302	*EF-601301	FUSE SEMKO T 250V 2.00A [U]
J301	*EJ-384277J	SOCKET OUTLET M7037 2P [U]
L301	*EO-338409	COIL LF FKOB160MH02 250UH
RL301	EQ-394450J	RELAY POW DG12D1-O(M) 12V
TR301	ET-356336	TR DTA114ES
TR302	ET-354371	TR DTC124ES
TR303	ET-749375	TR 2SC2458 GR [U]
TR304	ET-366365	TR 2SB1185 E,F [U]

#### 12. FUSE-1 P.C BOARD

Ref.No.	Part No.	Description
F401A	*EF-691007	FUSE SEMKO T 250V 3.15A [AM-M600]
F401B	*EF-690996	FUSE SEMKO T 250V 4.00A [AM-M800]
F402A	*EF-691007	FUSE SEMKO T 250V 3.15A [AM-M600]
F402B	*EF-690996	FUSE SEMKO T 250V 4.00A [AM-M800]
F403	*EF-593706	FUSE SEMKO T 250V 500MA
F404	*EF-593706	FUSE SEMKO T 250V 500MA
F405	*EF-601942	FUSE SEMKO T 250V 630MA

#### 13. FUSE-2 P.C BOARD

Ref.No.	Part No.	Description
F406	*EF-601942	FUSE SEMKO T 250V 630MA
F407	*EF-601942	FUSE SEMKO T 250V 630MA
F408	*EF-601301	FUSE SEMKO T 250V 2.00A

#### 14. FINAL ASSEMBLY


Ref.No.	Part No.	Description
1 <b>A</b>	BD-A2068A050A	PANEL FRONT BLK AM-M600-B
1B	BD-A2068A050B	PANEL FRONT BLK AM-M800-B
2	SK-394133M	BUTTON POW
3	SK-394100M	BUTTON INPUT
4	SK-394101M	BUTTON DYNAMIC
		[AM-M800]
5	SE-395118M	PLATE MASK
		[AM-M800]
6	SE-394119M	LENS OPTICAL
7	SK-394132M	BUTTON SP
		[AM-M800]
8	SK-394097M	KNOB VR
9	SK-394131M	KNOB TONE
10	SZ-394137M	DOOR
11.	SE-394190M	PLATE FOOT
12	ZW-394496J	CANOE CLIP NO.74
13	SA-394136M	CUSHION FOOT
14	SA-394127M	FOOT REAR
15A	SP-394107M	PANEL REAR AM-M600(U)
15B	SP-394106M	PANEL REAR AM-M600(E)
15C	SP-395832M	PANEL REAR AM-M600(V)
15D	SP-394368M	PANEL REAR AM-M600(B)
15E	SP-394109M	PANEL REAR AM-M800(U)
15F	SP-394108M	PANEL REAR AM-M800(E)
15G	SP-395833M	PANEL REAR AM-M800(V)
15H	SP-394369M	PANEL REAR AM-M800(B)
16	EJ-394538J	TERMIMAL W/S 0033-208-0-00
17	*ES-349070	SW SELECTOR YKS11-0002 02-4 [U]
18	SC-394094M	COVER UPPER AM
19	EJ-394657J	PLUG SHORT-PIN CNT31-0074
20A	*BT-394522J	TRANS POW A2068(U)
		[AM-M600]
20B	*BT-394523J	TRANS POW A2068(E)
		[AM-M600]
20C	*BT-394524J	TRANS POW A2068(B)
		[AM-M600]
20D	*BT-394526J	TRANS POW A2067(U)
		[AM-M800]
20E	*BT-394527J	TRANS POW A2067(E)
		[AM-M800]
20F	*BT-394528J	TRANS POW A2067(B)
		[AM-M800]
21A	*EW-374894	AC CORD 2C VM-0129A,VFF U/T
21B	*EW-347897	AC CORD 2 CORES VM0364,LCFL EV
21C	*EW-346249	AC CORD 2 CORES LCFL2X0.75 B
22	*EZ-371605	BUSH CORD 2271
23	ZS-387983J	ST BID30X08STL BNI EARTH LOCK
24	ZS-331182	BT BID30X08STL BNI
25	ZS-346742	ST BID40X08STL CMT CUP

#### NOTE:

Parts will not be supplied if they are not listed in the parts list, even if they appear on the assembling illustrations with reference No.

#### 15. ACCESSARY

Ref.No.	Part No.	Description
1	AX-394557M	REMOCON RC-S600



### **MEMO**

## ABBREVIATIONS (AMPLIFIER)

ABBREVIATION	EXPLANATION
A	Analog
AC	Alternating Current
AMP	AMPlifier
CD	Compact Disc
СОМ	COMmon
D	Digital
D/A	Digital to Analog
DAC	Digital to Analog Converter
DAT	Digital Audio Tape recorder
DC	Direct Current
GND	GrouND
L	Left
LED	Light Emitting Diode
MC	Moving Coil
MM	Moving Magnet
PCB	Printed Circuit Board
R	Right
REG	REGulator
REC	RECord
TR	TRansistor
SW	SWitch
V.AMP	Voltage AMPlifier
V.DISC	Video DISC
VR	Variable Resistance
VTR	Video Tape Recorder


# **AKAI**


# MODEL AM-M600 MODEL AM-M800

# SCHEMATIC DIAGRAMS AND PC BOARDS


#### TABLE OF CONTENTS

1.	BLOCK DIAGRAM	3
2.	FUSE 1 AND OTHER PC BOARDS	4
3.	CONNECTION DIAGRAM	5
4.	MAIN SCHEMATIC DIAGRAM	6
5.	MAIN AND JACK PC BOARDS	7
6.	CONTROL SCHEMATIC DIAGRAM	8
7.	CONTROL AND OTHER PC BOARDS	9
8.	AM-M600 DAC-A SCHEMATIC DIAGRAM	10
	DAC-A PC BOARD	
<b>0.</b>	DAC-B PC BOARD	12
1.	AM-M800 DAC-B SCHEMATIC DIAGRAM	13
12.	INFORMATION OF ICS	14






FUSE 2 PCB A2067A50IE





FILTER PCB A2067A50IC B E V model





WARNING: AINDICATES SAFETY CRITICAL COMPONENTS FOR CONTINUED SAFETY.
REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S
RECOMMENDED PARTS


AVERTISSEMENT: ÀIL INDIQUE LES COMPOSANTS CRITIQUES DE SÉCURITÉ. POUR MAINTENIR LE DEGRÉ DE SÉCURITÉ DE L'APPAREIL. NE REMPLACER QUE DES PIÈCES RECOMMANDEES PAR LE FABRICANT

















CONNECTORS J1.........B6 IC5......A3 TR101.....E3 J3.....E6 IC6.....B3 TR102.....D1 J4.....F6 IC7.....A1,2 TR103.....E1 IC8.....B1,2 TR104.....D5 J8.....B1 TR105.....F6 IC101.....D3 J9.....E,F1 TR106.....F5 J10......G1 J12.....E4 J13.....F4,5 J14.....F4

WIRE

W1.....E5,6


\*Indicated --------are  $\bigvee$  model only





+ + SPEKER B AM - MBOO ONLY


WARNING: AINDICATES SAFETY CRITICAL COMPONENTS FOR CONTINUED SAFETY.
REPLACE SAFETY CRITICAL COMPONENTS ONLY WITH MANUFACTURER'S
RECOMMENDED PARTS


AVERTISSEMENT: ÀIL INDIQUE LES COMPOSANTS CRITIQUES DE SÉCURITÉ.
POUR MAINTENIR LE DEGRÉ DE SÉCURITÉ DE L'APPAREIL,
NE REMPLACER QUE DES PIÈCES RECOMMANDEES PAR LE FABRICANT












#### PRINCIPAL PARTS LOCATION

TRANSISTORS
TR1A3
TR2B1
TR3B1
TR4A1
TR5A1
TR6
TR7A3
TR8B2
TR9B2
TR10B1
TR11B1
TR12A3
TR13A3
TR14A3
ICS
IC1B4
IC2B3
IC3B3
IC4B2

CONNECTORS


J2.....A2


J3.....B1




#### PRINCIPAL PARTS LOCATION

TRAN	IS	IS	ST	0	R	S			
TR1.							В	2	
TR2.					•	•	A	3	
TR3.						•	A	3	
TR4.							A	2	
TR5.					•	*	A	2	
TR6.						•	A	1	
TR7.						•	A	1	
TR8.							A	2	
TR9.							A	2	
ICS									
IC1.							C	1	
IC2.							C	2	
IC3.							В	2	
IC4.							В	2	
IC5.							В	1	
IC6.							A	1	
CON	NE	C	TC	)F	S				
J1.		•					D	2	
J2.							A	,B2	
J3.							B	,C1	
J4.									
J5.		-			•		D	1,2	





#### LC6520-4318 (MI-CON)



#### PD0050 (Over Sampling Digital Filter)


PIN NO	SYMBOL	I/O	FUNCTION
1	X IN	I	X'tal OSC Input
2	хоит	0	X'tal OSC Input
3	MODE 1	I	H: 16.9344 MHz L: 8.4672 MHz
4	CK OUT	0	MODE 1 (H): 16.9344 MHz Clock out. MODE 1 (L): 8.4672 MHz Clock out
5	LRCK	I	LRCK Input
6	DATA	I	Serial DATA Input
7	BCLK	I	BCK Input
8	VSS	_	−B (OV)
9	MODE 2	I	H: 18 bit DATA Output L: 16 bit DATA Output
10	SH OUT	0	Sampling Hold Pulse out
11	LD OUT	0	DATA OUT (Lch)
12	RD OUT	0	DATA OUT (Rch)
13	MODE 3	I	MODE 3 (H): MODE 3 (L): 20 bit DATA out
14	WOUT	0	Word Clock out
15	BOUT	0	LD OUT, RD OUT
16	VDD	-	+B (+5V)

#### PD0052 (Digital Audio Interface Receiver)

PIN NO.	SYMBOL	I/O	DESCRIPTION	
1	IN 1	ı	Digital Audio Interface signal input.	
2	IN 2	ı		
3	IN 3	1		
4	S 1	1	Input select 1.	
5	S 2	ı	Input select 2.	
6	OUT	0	Data output.	
7	TEST	1	TEST MODE input.	
8	RESET	1	Power "ON" Reset input.	
9	VCOINH	1	VCO OSC Stop Control signal input.	
10	VSS	-	GND	
11	PCVS	ı	External Resistor Connection Terminal for VCO.	
12	PC OUT	0	Phase comperator output.	
13	R	-	External Resistor Connection Terminal for VCO.	
14	VCO IN	ı	Control voltage input.	
15	VDD 1	-	+B (+5 V)	
16	VCO OUT	0	VCO Output (384 fs)	
17	VSS 1	-	GND	
18	CA	-	External Canaditar Canadation Terminal for VCO	
19	СВ	-	External Capacitor Connection Terminal for VCO.	
20	MODE	-	GND	
21	BCK	0	Bit clock output.	
22	DATA	0	Data output.	
23	LRCK	0	Data output. (H=L ch, L=R ch)	
24	COPY	0	Copy inhibit information output.	
25	EMPH	0	H: EMPHASIS	
26	ERR	0	H: Parity Error, L= NO ERROR	
27	48 K	0	Sampling Frequency data output. L=active	
28	44.1 K	0		
29	32 K	0		
30	VDD	-	+B (+5 V)	

#### SM5807EP (4fs Over Sampling Digital Filter)

PIN NO.	SYMBOL	1/0	DESCRIPTION
1	XT	ı	X'tal OSC input.
2	ΧT	0	X'tal OSC output.
3	CKSL	ı	H: 16.9344 MHz L: 8.4672 MHz
4	СКО	0	Clock output.
5	LRCI	1	Clock input.
6	D IN	I	Serial data input.
7	B CKI	ı	Bit clock input.
8	VSS	-	GND
9	SCSL	ı	H: 192 fs L: 196 fs
10	DGR	0	R ch signal output.
11	DGL	0	L ch signal output.
12	D OUT	0	Serial data output.
13	WDCO	0	Control clock output. (352.8 kHz)
14	LRCO	0	Control clock output. (176.4 kHz)
15	BCKO	0	Bit clock output.
16	VDD	-	+B (+5 V)



15

## **AKAI ELECTRIC CO., LTD.**

12-14, 2-Chome, Higashi-Kojiya, Ohta-ku, Tokyo, Japan SERVICE DEPARTMENT TEL:Tokyo (745)9884 TELEX:J26261 Printed No. 900406-A1-3000 Printed Date May 10, 1990 350 Printed in Japan